How to Operator your Bio Light 120 Lumen V6A.

- 1. Press and hold the push button for 3 seconds and release. The 7 LEDs should begin running anti-clockwise.
- 2. Press and hold the push button. Watch the red LED and count the number of times it blinks.
 - a. One blink = 15 minutes until auto-off.
 - b. Two blinks = 60 minutes until auto-off.
 - c. Three blinks = Only the center LED lights so you can use it as a torch light.
 - d. Four, five, seven, eight or nine blinks = Light will turn off.
 - e. Six blinks = Change rotation speed. Then push Green LED 1-6 times to select desired speed. 1 is fast, 2 is slower, etc. 6 is slowest speed.

Battery Level Indicator

When the light is turned off, the Green LED will blink to show the battery charge level. If it blinks less than 3 times, charge the battery immediately to avoid damaging the battery and reducing the life of the battery. When the battery is low, it should be charged for 8 hours before you use it again. While the battery is charging, the Red LED will blink. When the battery is fully charged, the Red LED will stay on solid.

Warning: Do NOT shine light directly into your eyes.